


Power-Wave

Air Circuit Breaker Draw Out - 50, 65 kA



Air Circuit Breaker
manual and electrical operated
Draw out pattern : breaker and cassette
with flat copper terminal, rear connected
including 5 NO and 3 NC auxiliary switch

| Cat. No. 50 kA | Ref. No. | Cat. No. 65 kA | Ref. No. | Frame | Rating (A) | Position of the | Poles |
|----------------|----------|----------------|----------|-------|------------|-----------------|-------|
| FTCPWS31W04-A | F101274 | FTCPWN31W04-A | F102084 | 1 | 400 | | 3 |
| FTCPWS4L1W04-A | F101275 | FTCPWN4L1W04-A | F102085 | | | LEFT | 4 |
| FTCPWS4R1W04-A | F101276 | FTCPWN4R1W04-A | F102086 | | | RIGHT | 4 |
| FTCPWS31W06-A | F101277 | FTCPWN31W06-A | F102087 | 1 | 630 | | 3 |
| FTCPWS4L1W06-A | F101278 | FTCPWN4L1W06-A | F102088 | | | LEFT | 4 |
| FTCPWS4R1W06-A | F101279 | FTCPWN4R1W06-A | F102089 | | | RIGHT | 4 |
| FTCPWS31W08-A | F101280 | FTCPWN31W08-A | F102090 | 1 | 800 | | 3 |
| FTCPWS4L1W08-A | F101281 | FTCPWN4L1W08-A | F102091 | | | LEFT | 4 |
| FTCPWS4R1W08-A | F101282 | FTCPWN4R1W08-A | F102092 | | | RIGHT | 4 |
| FTCPWS31W10-A | F101283 | FTCPWN31W10-A | F102093 | 1 | 1000 | | 3 |
| FTCPWS4L1W10-A | F101284 | FTCPWN4L1W10-A | F102094 | | | LEFT | 4 |
| FTCPWS4R1W10-A | F101285 | FTCPWN4R1W10-A | F102095 | | | RIGHT | 4 |
| FTCPWS31W12-A | F101286 | FTCPWN31W12-A | F102096 | 1 | 1250 | | 3 |
| FTCPWS4L1W12-A | F101287 | FTCPWN4L1W12-A | F102097 | | | LEFT | 4 |
| FTCPWS4R1W12-A | F101288 | FTCPWN4R1W12-A | F102098 | | | RIGHT | 4 |
| FTCPWS31W16-A | F101289 | FTCPWN31W16-A | F102099 | 1 | 1600 | | 3 |
| FTCPWS4L1W16-A | F101290 | FTCPWN4L1W16-A | F102100 | | | LEFT | 4 |
| FTCPWS4R1W16-A | F101291 | FTCPWN4R1W16-A | F102101 | | | RIGHT | 4 |
| FTCPWS31W20-A | F101292 | FTCPWN31W20-A | F102102 | 1 | 2000 | | 3 |
| FTCPWS4L1W20-A | F101293 | FTCPWN4L1W20-A | F102103 | | | LEFT | 4 |
| FTCPWS4R1W20-A | F101294 | FTCPWN4R1W20-A | F102104 | | | RIGHT | 4 |
| FTCPWS31W25-A | F101295 | FTCPWN31W25-A | F102105 | 1 | 2500 | | 3 |
| FTCPWS4L1W25-A | F101296 | FTCPWN4L1W25-A | F102106 | | | LEFT | 4 |
| FTCPWS4R1W25-A | F101297 | FTCPWN4R1W25-A | F102107 | | | RIGHT | 4 |
| FTCPWS32W20-A | F101298 | FTCPWN32W20-A | F102108 | 2 | 2000 | | 3 |
| FTCPWS4L2W20-A | F101299 | FTCPWN4L2W20-A | F102109 | | | LEFT | 4 |
| FTCPWS4R2W20-A | F101300 | FTCPWN4R2W20-A | F102110 | | | RIGHT | 4 |
| FTCPWS32W25-A | F101301 | FTCPWN32W25-A | F102111 | 2 | 2500 | | 3 |
| FTCPWS4L2W25-A | F101302 | FTCPWN4L2W25-A | F102112 | | | LEFT | 4 |
| FTCPWS4R2W25-A | F101303 | FTCPWN4R2W25-A | F102113 | | | RIGHT | 4 |
| FTCPWS32W32-A | F101304 | FTCPWN32W32-A | F102114 | 2 | 3200 | | 3 |
| FTCPWS4L2W32-A | F101305 | FTCPWN4L2W32-A | F102115 | | | LEFT | 4 |
| FTCPWS4R2W32-A | F101306 | FTCPWN4R2W32-A | F102116 | | | RIGHT | 4 |
| FTCPWS32W40-A | F101307 | FTCPWN32W40-A | F102117 | 2 | 4000 | | 3 |
| FTCPWS4L2W40-A | F101308 | FTCPWN4L2W40-A | F102118 | | | LEFT | 4 |
| FTCPWS4R2W40-A | F101309 | FTCPWN4R2W40-A | F102119 | | | RIGHT | 4 |